



CN3 Connector : Supply Input 5 VDC  
 CN1 Connector : Aux Audio Input  
 CN2 Connector : Output  
 PR1 Preset : Input Signal Audio Level Adjust  
 J1 : M - Mic input, A - Aux Audio Input

For Echo Mode :  
 Omit : C17  
 PR3 Preset : Echo Effect Sound Delay Adjust  
 PR2 Preset : Echo Depth Adjust

For Surround Mode :  
 Omit : R10, R14 & C13  
 PR3 Preset : Sound Delay Adjust