



BATTERY HOLDER KEYSTONE # 1294
 DIGIKEY PART NNO 36-1294-ND
 SLIDE SWITCH DIGIKEY # EG1917-ND