



LMD18200 DIR=D11, PWM=D5
 ENCODER A CHANNEL D2
 ENCODER B CHANNEL D3
 ENCODER SWITCH D4
 LMD18200 BRAKE A1

