



JUMPER J5 = OPEN FOR DUAL +/-5V SUPPLY, CLOSED FOR SINGLE 5V DC SUPPLY
 Linear Mode: Jumper J2, J3, J5 = Open, Jumper J1 = Closed, J4=GND

Setpoint Controller Mode: Jumper J1, J3, J5 = Open, Jumper J2 Closed and J4=GND, CN1 Pin 5 Set Point Voltage input
 Pin 4 = High or Low Output

Hysteresis on Setpoint Controller Mode: Jumper J1, J5=Open, J4 = Resistor Divider R5/R6, J3=Closed, J2=Closed